The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.



1 A3 ********** DATA TABLE

STANDARD GROUPS

1 A7 ********* VALUE

FICHE LOCATION ILLUSTRATION 1 A7 ********* CAMSHAFT 1 All ********* CARBURETOR PARTS 1 A13 ******** CARRYING FRAME AND BATTERY 1 A9 ********* CONNECTING ROD AND PISTON 1 B3 ********* CONTROL 1 A7 ******** CRANKSHAFT AND FLYWHEEL 1 A5 ******* CYLINDER BLOCK, OIL BASE AND GEAR COVER 1 B1 ******** DOLLY-OFTIONAL 1 A11 ********* FUEL SYSTEM 1 B1 ******** FUEL SYSTEM (LPG)-OPTIONAL 1 B5 ********* GENERATOR 1 A13 ********* GOVERNOR AND THROTTLE 1 A13 ******* HOUSING, STOP BUTTON AND GAGE 1 A9 ********* IGNITION 1 A13 ********* PUMP PARTS, FUEL 1 All ********* PUMP, OIL




927-1060 225 AMP WELDER - CCK SERIES PARTS CATALOG

This catalog applies to the 225 Ampere Welder. Parts are arranged in groups of related items. Each illustrated part is identified by a reference number corresponding to the same reference number below the illustration. Parts illustrations are typical. Unless otherwise mentioned in the description, parts are interchangeable between models. Right and left welder sides are determined by facing the engine end (front) of the welder.

The Specification Letter, which completes the specification on the nameplate (Example: 7.0CCK-381E/1J) advances (A to B, B to C etc.) with manufacturing changes. Welders with the suffix numbers 4323, 4324, 4325, or 4443 (following the diagonal line) are the same as number 1, except the paint color.






REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	509-0008	1	Seal, Governor Shaft	25	110-1283	- 1	*Cover, Timing Control - Spec J
2	510-0013	1	Bearing, Governor Shaft - Upper				through M
3	150-0377	i	Shaft and Arm, Governor	25 A	517-0048	1	Plug, Camshaft - Expansion -
4	150-0236	1	Yoke, Governor Shaft				Begin Spec L
5.	518-0129	. 1	Ring, Yoke Retainer	26	520-0114	5	*Stud, Rear Bearing Plate Mountin
6	516-0130	j	Pin, Roll - Governor Cup Stop		-		- 5/16 x 1-5/16 ~
7	510-0008	1	Bearing, Governor Shaft - Lower	27	110-0445	5	*Nut, Rear Bearing Plate
8	510-0014	ı	Ball, Bearing - Governor Shaft	28	851-0005	5	*Washer, Lock - 5/16 x Special
9	509-0040	1	Seal, Oil - Gear Cover				Width - Rear Bearing Plate
10	150-1000	i	Extension, Governor Arm - Fastens	29	102-0440	1	Base, Oil
			to Governor Arm	29A	123-0901	1	Tube, Oil Fill
11	815-0181	1	Screw, Self Tapping - Bracket	30	123-0882	1	Cap, Oil Fill - Includes Cap
			Fastening - 10-32 x 1/2"				Gasket & Oil Level Indicator
12	103-0207	1	Cover Assembly Gear - includes	31	123-0191	1	Gasket, Oil Fill Cap
			Cover plus Items I through II	32	102-0158	l	Gasket, Oil Base Mounting
13	103-0011	ŀ	Gasket, Gear Cover	33	ELBOW, OI	L DRAIN	4.
14	110-1516	1	Block Assembly Cylinder Includes	l	505-0120	1	Early Models 3/8″ - 90°
			Parts Marked *	}	505-0050	1	Later Models 1/2" - 90°
15	516-0011	2	*Pin, Gear Cover - 5/16 x 1-1/8"	34	NIPPLE, O	IL DRAIN	., .,
16	120-0386	I	*Tube, Oil - Crankcase Internal.	1	505-0125	ŀ	Early Models 3/8 (x 6 "
			To Rear Main Bearing	i	505-0082	l	Later Models 1/2"x 5-1/2"
17	123-0293	ŀ	Cap, Breather Tube Rubber	35	COUPLING	, OIL DRA	
18	123-0129	1	Tube, Breather - Less Valve &	Ì	505-0028	J	Early Models 3/8
			Baffle		505-0014	i	Later Models 1/2"
21	123-0104	1	Valve, Breather Tube	36	504-0080	l	Valve, Oil Drain - 3/8"
22	110-0666	2	Cover, Valve Compartment	37	502-0020	1	Elbow, Street - Oil Line to Block
23	110-0667	2	Gasket, Valve Complete Cover	38	110-0892	2	Gasket Cylinder Head
24	526-0063	2	Washer, Copper - Valve Complete	39	110-0884	1	Head, Cylinder - RH
			Cover	40	110-0883	1	Head, Cylinder - LH
				* .	- Parts Inclu	ded in Cyli	inder Block Assembly.



REF.	PART NO.	QTY.	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART <u>Description</u>
41	*BEARING KI	T, CRAN	KSHAFT - PRECISION		SCREW, CA	P-HEX	IFAD
	101-0420	2	Standard	57	800-0011	2	1/4-20 x 2 " - Valve Complete
	101-0420-02	2	.002 ' Undersize	•	• • • • •	_	Cover Mounting .
	101-0420-10	2	.010 '' Undersize	58	110-0879	8	5/16-18 x 1-1/4 " - Cylinder Hear
	101-0420-20	2	.020 '' Undersize			-	Mounting
	101-0420-30	2	.030 ′′ Undersize	59	114-0022	10	5/16-18 x 1-3/4 " - Cylinder Hear
42	104-0575	2	Washer, Crankshaft Bearing				Mounting
			Thrust - Included in Bearing Kit	60	800-0032	4	5/16-18 x 1-3/4 * - Gear Cover Mounting
43	516-0072	4	Pin, Crankshaft Thrust Washer Lock - Included in Bearing	61	800-0034	1	5/16-18 x 2-1/4 "- Gear Cover Mounting
			Kit	62	102-0455	4	3/8-16 x 1-1/4 " - Oil Base Moun
44	101-0115	ļ	*Gasket Kit, Rear Bearing Plate	63	800-0037	2	5/16-18 x 3 "- Engine Mounting
45	101-0316	ì	*Plate, Rear Bearing (Less Bearing)	64	800-0050	2	3/8-16 x 1 " - Generator Support Mounting
46	101-0367	. 5	*Bearing, Camshaft - Front & Rear	65	526-0076	2	Washer, Flat - Generator Mtg.
47	505-0019	1	Bushing, Reducer Oil Drain				(11/32)
			(1/2" to 3/8") - Later Models Only	66	526-0076	4	Washer, Flat - Engine Mtg. (11/32)
48	509-0041	1	Seal, Oil - Rear Bearing Plate	67	526-0080	2	Washer, Flat - Generator Support
49	232-1368		Support, Generator				(3/8)
50	402-0226	SEMBLY 2	, PLANT MOUNTING Engine End	68	850-0050	2	Washer, Lock - Generator Support (3/8)
51	402-0223	2	Generator End	69	850-0045	5	Washer, Lock - Gear Case Mtg.
52	402+0038	2	Cushion, Mig. (Lower) Engine End	70	850-0050	4	Washer, Lock - Oil Base Mtg.
53	402-0131	4	Cushion, Mtg. (Upper) Engine End				(3/8)
		_	(2), Generator End (2)	71	870-0048	2	Nut, Huglock - Engine Mtg.
54	402-0137	2	Bushing, Spacer - Engine End				(5/16-18)
55	402-0192	2	Cushion, Mtg. (Lower) Generator End	72	870-0045	2	Nut, Huglock - Generator Mtg. (5/16-18)
56	4 02-01 9 3	2	Bushing (Sleeve), Mounting -	73	102-0558	ı	Heater, Oil Base (Optional)
			Generator End	, 74	141-0078	į	Gasket, Oil Fill Tube Mounting


* - Parts Included in Cylinder Block Assembly






NO.	NO.	USED	DESCRIPTION
1	150-0078	J	Ring, Camshaft Center Pin Snap
2	150-0612	1	Cup, Governor
2 3	510-0015	5	Ball, Fly - Governor
4	CAMSHAFT		
	105-0234	1	Spec J through M
	105-0238	I	Begin Spec L
5	150-0075	1	Pin, Camshaft Center
6	105-0353	ļ	Gear Set, Timing - Includes Crank
			Gear, & Cam Gear with Flyball
			Spacer & Plate (also in Crank-
			shaft & Flywheel Group)
7	105-0004	1	Washer, Thrust, Cam Gear
8	515-0001	ſ	Key, Camshaft Gear Mounting
12	516-0144	4	Pin, Roll - 7/16" Timing Control - Spec through M
13	160-0789	2	Weight Assembly, Includes Pins -
1.3	100-0707	2	Timing Control - Spec J thru M
14	516-0146	2	Pin, Groove - 1" - Timing Control
, 4	210 0110	2	Cam - Spec J through M
15	160-0726	1	Retainer, Timing Control -
, _	,00 0,20	•	Spec J through M
16	110-1283	1	Cover, Timing Control - Spec
			through M
17	160-0727	ł	Spring, Timing Control - Spec J
			through M
18	518-0185	2	Lock, Timing Control - Spec J
			through M
19	160-0791	!	Cam, Timing Control - Spec J
			through M






REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
1 2 3	110-0880 INSERT, 110-0872 110-1000 110-0904	2 2 VALVE SEAT 2 2 4	Valve, Intake - Stellite Valve, Exhaust - Stellite - STELLITE Exhaust Intake Rotocap, Valve	5 6 8 9	110-0902 110-0539 110-0639	4 4 8	Guide, Valve Spring, Valve Lock, Rotocap or Spring Retainer Washer Tappet, Valve




REF.	PART NO.	QTY. USED	PART DESCRIPTION
ŧ	526-0017	1	Washer, Flywheel Mounting
2	515-0002	1	Key, Flywheel Mounting - Steel
3	104-0170	Į.	Screw, Flywheel Mounting
4	FLYWHEEL,	MAGNET	O - LESS ROPE SHEAVE
	160-0761	1	Spec J through M
	160-0937	1	Begin Spec L
5	192-0308	l	Sheave, Rope
6	518-0014	1	Lock, Crankshaft Gear Washer
7	104-0043	i	Washer, Crankshaft Gear Retainer
8	105-0353	l	Gear Set, Timing - Includes Crank Gear & Cam Gear with Flyball Spacer & Plate - (Also in Camshaft Group)
9	104-0578	ł	Crankshaft
10	515-0001	ţ	Key, Crank Gear Mounting
11	192-0083	1	Rope Starting
12	850-0055	1	Lockwasher Mounting Flywheel (7/16)






REF.	PART NO.	QTY.	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART Description
3	PISTON & PI	N ASSEM	BLY - Includes Retainer Rings	7	RING SET, P	ISTON	
	112-0073	2	Standard	1	113-0089	2	Standard
	112-0073-05	2	.005" Oversize	l	113-0089-05	2	.005´´ Oversize
	112-0073-10	2	.010 "Overšize	İ	113-0089-10	2	.010´´ Oversize
	112-0073-20	2	.020 "Oversize		113-0089-20	2	.020´´ Oversize
	112-0073-30	2	.030 "Oversize	1	113-0089-30	2	.030 " Oversize
	112-0073-40	2	.040 '' Oversize	1	113-0089-40	2	.040 "Oversize
4	112-0069	2	Pin, Piston - Specify: Std.	8	805-0010	4	Bolt, Place - Connecting Rod
5	112-0003	4	Ring, Piston Pin Retainer	1	-		Caps
6	114-0144	2	Rod, Connecting (Forged) - Includes Bushing & Place	111	114-0036	2	Bushing, Piston Pin - Connecting Rod
			Bolts	12	BEARING HA	ALF. CON	INECTING ROD
				1	114-0145	4	Standard
				1	114-0145-02	4	.002" Undersize
					114-0145-10	4	.010" Undersize
			,	1	114-0145-20	4	.020 ~ Undersize
				1	114-0145-30	4	.030'' Undersize






NO.	NO.	USED	DESCRIPTION
. 1	160-0930	1	Cover, Breaker Box
2	160-0150	J	Gasket, Breaker Box Cover
3	160-0075	1	Cam, Point Gap Adjusting
4	160-0002	1	Point Set, Ignition Breaker
6	312-0069	1	Condenser, Breaker Box - 0.3 Mfd.
7	336-1022	1	Lead, Breaker Box to Ignition Switch
8	160-0043	ł	Gasket, Breaker Box
10	160-0723	I	Plunger Only, Breaker
10B	160-1143	1	Diaphragm, Breaker Plunger
11	167-1404	1	Cable, Spark Plug - RH
13	167-1403	1	Cable, Spark Plug - LH
14	160-0750	Ť	Coil, Magneto Stator
15	160-0749	ļ	Pole Shoe, Magneto Stator
16	167-0241	2	Plug, Spark
17	160-0963	1	Box Assembly, Ignition Breaker - Includes Cover & Gasket
2 2	160-0428	ţ	Strap, Point Set to Breaker Box Terminal Block
23	160-0349	ŀ	Block and Terminal, Breaker Box
28	160-026	ı	Wick, Breaker Box
30	167-0188	4	Clip, Spark Plug Cable
31	160-0929	1	Bushing, Breaker Box Plunger
32	526-0015	4	Washer, Poleshoe Mounting (11/16" Thick)
33	815-0259	2	Screw, H.H. Thread Cutting Mtg. Stator (1/4-20 x 1-3/8'')
34	850-0040	2	Lockwasher, Mounting Stator (1/4")
35	526-0184	2	Flatwasher Mounting Stator
36	815-0037	2	Screw, R.H. x Rec M W/ET Mtg. Breaker Box (1/4-20 x 7/8")
37	812-0077	2	Screw, RHSM Mounting Breaker Box (8-32 x 3/8'')
38	850-0025	2	Lockwasher, Mounting Breaker Box (#8)








REF.	PART No.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	145-0094	1	Inlet, Carburetor Air	. 15	149-0045	1	Spacer, Fuel Pump
2	503-0280	1	Clamp, Air Inlet to Air Cleaner	16	149-0003	2	Gasket, Fuel Pump & Spacer Mt
3	503-0107	f	Clamp, Air Inlet to Carburetor	17	149-0775	1	Line, Fuel Pump to Carburetor
4	140-0537	F .	Housing, Air Cleaner	18	154-0601	t	Manifold, Intake
5	140-0538	1	Cover, Air Cleaner	19	141-0078	1	Gasket, Carburetor Mounting
6	140-0495	ı	Cartridge, Air Cleaner	20	33 1-0053	2	Nut, Pipe - I" - Exhaust Outlet
7	518-0056	ı	Screw, Wing - Air Cleaner Cover	21	505-0003	2	Elbow, Street - 1" - Exhaust Ou
			Mounting	22	505-0087	2	Nipple, Close - 1"x 3"-Exha
В	142-0416	j	Carburetor Assembly	•			Outlet
9	149-0693	1	Pump Assembly, Fuel	23	155-0484	2	Muffler, Exhaust
10	502-0002	2	Elbow, Inverted Male - (1) Fuel	24	153-0263	1	Bracket & Clip, Manual Choke
			Pump Outlet (I) Carburetor Inlet	25	154-0013	2	Gasket, Intake Manifold
11	502-0020	1	Elbow, St. Fuel Pump Inlet	26	153-0165	1	Choke, Manual
13	806-0009	2	Screw, Counterbore - 1/4-20 x	27	TANK, FUE	L	The state of the s
		_	1-1/4")		159-0690	I	Spec J through M
14	134-1019	t	Baffle, Fuel Pump Air	•	159-0946	1	Begin Spec M



REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY.	PART Description
28	STRAP, FUE!	LTANK	MOUNTING Spec through M	37	850-0050	2	Lockwasher Intake Manifold Mtg.
29	159-0947 159-0020	Ì	Begin Spec M Cap, Fuel Tank	38	800-0009	2	Screw, H.H. Carburetor Mounting
30	501-0007	İ	Line, Flex Fuel - Tank to Pump (24")	39	850-0040	2	to Manifold (1/4-20 x 1-1/2") Lockwasher, Carburetor Mtg. to Manifold (1/4)
3 I 32	159-0695 149-1170	ļ 1	Tube, Pick-Up - Fuel Tank Outlet Elbow & Screen, Fuel Tank	40	8/3-0100	t	Screw, RHMS Mtg. Shield (F.P.) (10-32 x 1/2")
33	505-0008	1	Plug, Slotted Pipe - Fuel Tank Drain	41 42	850-0030 806-0009	. 1	Lockwasher Mtg. Shield (F.P.) #
34	140-0554	į	Spacer, Air Cleaner	72	606-0007	2	Screw, Counterbore Mounting Pur (1/4-20 x 1-1/4")
35	420-0169	1	Wrench, Carburetor Adjusting	43	856-0043	1	Washer, Shakeproof Mounting Air
36	800-0054	2	Screw, H.H. Intake Manifold Mtg. $(3/8-16 \times 2'')$				Cleaner (#10)


CARBURETOR PARTS GROUP



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	142-0416	1	Carburetor Assembly
F	SCREW, BO	WL COVER	₹
	815-0103	1	#10-24 x 1/2′′
	815-0109	2	#10-24 x 5/8′′
2 .	815-0091	2	*Screw, Choke Fly - #4-40 x 3/16"
3	142-0055	1	Fly, Choke
4	142-0205	1	Sleeve, Choke (Cover)
5	142-0420	1	Shaft Assembly, Choke
6	142-0039	1	*Shaft, Float
7	142-0031	I	*Gasket, Body to Bowl
8	148-0017	2	Gasket (I) Float Valve Seat,
			(I) Main Adj. Needle Retainer
9	142-0049	l	*Valve Seat Assembly, Float
10	142-0032	ļ	*Gasket, Nozzie
11	142-0285	!	Nozzle Assembly
12	142-0361	ŀ	Float and Lever
13	145-0008	<u>!</u>	Lever, Idle Stop
14	142-0040	!	*Needle, Idle Adjusting
15	142-0282	!	Spring, Idle Needle Adjusting
16	142-0035	ļ	Spring, Throttle Stop Adj. Screw
17	812-0063	ı	Screw, Throttle Stop Adjusting - #6-32 x 1/2"
81	815-0072	2	*Screw, Throttle Fly - #4-40 x
19	142-0369	1	Fly, Throttle
20	142-0368	i	*Shaft Assembly, Throttle
21	142-0370	1	Nut & Jet, Nozzle
22	142-0046	ļ	Retainer, Main Adjusting Needle
23	142-0206	1	Packing, Main Adjusting Needle
24	142-0045	ŧ	Retainer, Main Adjusting Needle Packing
25	516-0027	1	Pin, Main Adjusting Needle
26	142-0041	1	*Needle, Main Adjusting
27			Body Assembly (Not Sold Separately)
28	505-0053	1	Plug, Gas Inlet
29	42-0343	2	Bushing, Throttle Shaft
30	142-0042	, I	Needle Assembly - Includes Packing, Nut & Retainer
31	142-0227	!	Pin, Choke Stop
	870-0053	1	Nut, Throttle Stop
	813-0102	ŀ	Screw, Throttle Stop Clamp - 10-32 × 5/8"
	142-0033	1	*Gasket Kit, Carburetor
	142-0371	1	Repair Kit, Carburetor (Includes Parts Marked *)


^{* -} Contained in Repair Kit #142-0371.





REF. No.	PART NO.	QTY. USED	PART DESCRIPTION
	49-0693	1	Pump Assembly, Fuel
	149-0526	1	Repair Kit, Fuel Pump (Includes
1		,	Parts Marked **)
	015 01 15		Body, Upper (Not Sold Sep.)
2	8/5-0148	4	Slotted Screw, H.H. (8-32 \times 1 $^{\prime\prime}$)
_	010010		Pump Assembly
3	815-0147	2	Screw, Phillips Flat Head
			(6-32 × 5/8") Valve Retainer
4	1-49-0096	2	*°Valve and Cage
5	149-0095	2	**Gasket, Valve
6	149-0582	į	**Diaphragm Assembly
· 🗦	149-0672	1	**Spring, Diaphragm
8	149-0539	1	Retainer, Valve Cage
9	149-0675	1	**Spring, Rocker Arm
10	516-0113	1	Pin, Rocker Arm
11		i	Body, Lower (Nct Sold Sep.)
12	149-0710	1	Arm & Link Set (Only as a Set)
13	518-0129	Į.	Ring, "E" Ret Priming Lever
14	149-0551	1	Lever, Hand Primer
15	509-0065	2	Seal, ''O'' Ring
16	149-0404	1	Spring, Priming Lever
17	149-0003	2	**Gasket, Fuel Pump & Spacer Mtg.
			(Also in Fuel System Group)
18	149-0858	1	**Gasket, Fuel Pump Diaphragm
			(Pull Rod Side)


** - Contained in Repair Kit #149-0526.



REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	150-1009	F	Stud, Governor Adjusting	10	152-0110	5	Plate, Adjusting - Speed Lever
2	150-0098	L	Spring, Governor				Travel
3	150-0974	1	Joint, Governor Link Ball	14	526-0015	!	Washer, Flat - Speed Lever
4	150-0629	1	Link, Governor Arm to Carburetor	15	870-0200	ŀ	Nut, Governor Adjusting Stud
5	518-0006	1 .	Clip, End - Link to Carburetor	16	870-0053	1	Nut, Hex - Governor Ball Joint
6	152-0143	1	Bracket, Variable Speed Governor				to Link
7	152-0134	1	Lever, Speed Adjusting	17	870-0131	1	Nut, Keps - Governor Ball Joint
8	152-0041	1	Washer, Tension - Speed Lever			-	to Governor Arm
9	870-0065	ı	Nut, Huglock - Speed Lever - 1/4-20	18	815-0293	1	Screw Thread Cutting Mtg. Speed Control (1/4-20 x 5/8")
				19	815-0265	I	Screw, H.H. Mtg. Speed Control (1/4-20 x 1/2")




HOUSING, STOP BUTTON AND GAGE	REF.	PART No.	QTY. USED	PART DESCRIPTION
	1	405-1184	1	Cover, Engine and Control
	2	405-1187	i	Cover, Lifting Eye
	3	134-0980	1	Housing, Cylinder Air - L.H. (#1 Cylinder)
	4	134-1579	F	Housing, Blower
	5 _	134-0979	1,	Housing, Cylinder Air - R.H. (#2 Cylinder)
	6	501-0004	i	Line, Flexible - Oil Gauge
	7	193-0005	i	Gauge, Oil Pressure
o man	10	502-0005	i	Elbow, Inverted Female - On Oil Gauge
111	1.1	508-0095	2	Grommet, Rubber
123	12	860-0012	2	Nut, Hex Mounting Oil Gauge (12-24)
3 610 7	13	853-0011	2	Washer, Shakeproof Mtg. Oil Gauge (#12)
1617	14	815-0265	2	Screw, H.H. Thread Cutting Mtg. Blower Housing (1/4-20 x 1/2")
, -	15	815-0261	1	Screw, H.H. Thread Cutting Mtg. Blower Housing (1/4-20 x 7/16")
	16	815-0261	4	Screw, H.H. Thread Cutting Mtg. Air Housing (1/4-20 x 1/2")
	۱7	853-0013	4	Washer, Shakeproof Mtg. Air Housing (1/4)



REF.	PART NO.	QTY. USED	PART DESCRIPTION
. 1	403-0754	1	*Frame, Carrying
2	403-0588	4	Tips, Rubber - Carrying Frame
3	416-0538	J	Rack, Battery
4	337-0036	j	Strap, Ground - Carrying Frame to Blower Housing
5	<16-0540	1	Frame, Battery Hold-down
6	416-0541	2	Stud, Battery Hold-down
7	416-0539	1	Battery, Starting - 12 Volt - Optional Equipment
8	CABLE, B	ATTERY T	O CONTROL
-	416-0553	i	Positive Post to Start Switch - 36"
	416-0534	1	Electrolyte, Battery

^{* -} Prior to Spec M also order (2) 159-0945 Brackets.






DOLLY GROUP (OPTIONAL EQUIPMENT)


REF. No.	PART NO.	QTY. USED	PART Description
	410-0287	ł	Dolly Assembly - Includes entire group plus hawe. (Does NOT include Carrying Frame)
1	410-0285	2	Handle
2	403-0205	2	Grip, Handle
3	4'0-0233	ŀ	Axle
4	410-0283	2	Support, Axie
5	410-0284	2 2 2 2	Plate, Axle Support
6	410-0143	2	Bolt, "U" - Axle Mounting
7	410-0236	2	Wheel and Tire Assy Includes Tube
8	518-0130	4	Ring, "E" Retainer - Dolly Wheel to Axle
9	526-0081	4	Washer, Flat - Wheel Mounting
10	800-0031	2	Screw, H.H. Handle Mounting (5/16-18 × 1-1/2")
11	814-0182	2	Screw, ().H. Handle Mounting (5/16-18 x 1-1/2'')
12	800-0035	2	Screw, H.H. Handle Mounting (5/16-18 × 2-1/2'')
13	850-0045	2	Lockwasher Handle Mounting (5/16)
14	862-0015	2.	Nut, Hex Handle Mounting (5/16-18)
15	850-0015	4	Lockwasher U Bolt (3/8)
16	862-0003	4	Nut, Hex U Bolt (3/8-16)





REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	502-0039	ļ	Elbow, Carburetor Inlet
2	159-0745	j	Line, Fuel - Vaporizer to Carb.
3	505-0099	Į.	Nipple, Vaporizer to Regulator
4	148-0418	j	Vaporizer Assembly
5	48-0423	1	Bracket, Vaporizer Mounting
6	149-0136	1	Cover, Grankcase, Fuel Pump Hole
7	502-0039	1	Elbow, Regulator Outlet
8	148-0465	1	Regulator, LPG - Secondary
9	141-0647	i	Carburetor, Pressure - LPG (Comb.) Carburetor & Pressure Regulator
	141-0653	1	Repair Kit, Carburetor
	141-0652	. 1	Gasket Kit, Carburetor
	141-0651	2	Seal, Throttle Shaft (Comb. of Carburetor)
	141-0650	2	Retainer, Throttle Shaft Seal (Comb. of Carburetor)






REF.	PART	QTY.	PART	REF.	PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION	NO.	NO.	USED	DESCRIPTION
1	301-2570	1	Box, Control	23	526-0101	1	*Washer, Flat - Insulator Rod Mtg
2	301-1340	1	Plate, Control Box Ventilation	24	868-0011	11	*Nut, Hex Jam - Jack Mounting
3	301-1339	1	Plate, Control Box Reflector	26	304-0467	1	*Element, Resistor
4	323-0184	į.	Receptaçle, Duplex	27	304-0466	2	*Element, Resistor
5	303-0112	1	Rheostat	29	304-0553	1	*Element, Resistor
6	304-0061	J	Knob, Rheostat	30	304-0465	2.	*Element, Resistor
7	304-0183	1	Resistor, Field - 5.5-Ohm, 160 Watt	31	304-0468	3	*Element, Resistor
8	304-0117	1	Bracket, Field Resistor Mounting	32	304-0554	ŀ	*Element, Resistor
9	301-2583	İ	Panel, Control Box	33	316-0045	2	Plug, Welding Cables
	RESISTOR,	BATTERY	CHARGE	34	304-0555	ŀ	Element, Resistor
10	304-0011	I	50-Ohm, 25 Watt (9/16 x 2/1)	35	332-0048	I	Clip, Control Leads
10A	353-0008	I	70-Ohm, 35 Watt $(3/4 \times 4'')$	36	WASHER,	RESISTOR	CENTERING
1.1	304-0470	2	Bracket, Battery Charge Resistor		304-0015	4	1/2″J.D. × 3/4″ O.D.
12	308-0028	ı	Switch, Start		304-0014	2	7/32 ~ 1.D. × 9/16 ~ O.D.
13	308-0069	I	Switch, Ignition	37	332-0928	2	Stud, 1/4-20 x 2″
14	308-0002	ļ	Switch, High - Low Charge Rate	38	301-2547	i	Bracket, Terminal Board Mtg.
15	301-1778		*Bracket, Resistor Elements Mtg.	39	30 I-2548	ı	Bracket, Terminal Board Mtg.
16	301-1777	1	*Block, Terminal - Resistor Element	40	332-0929	!	Board, Terminal
			Fastening	41	323-0410	ı	Housing, Connector Pins (9 Plac
17	316-0044	H	*Jack, Plug - Welder Cable	400		_	- Voltage Control Leads
			Connecting	42	323-0496	7	Pin, Connector - Voltage Control
18	308-0149	10	*Angle, Connector - Resistor Elements			_	Leads
			to Plug Jack - 1-23/32 "Long		323-0440	ı	Housing, Connector Socket (6 Pli
IBA	308-0128	3	*Angle, Connector - Resistor Elements				- Generator Leads
			to Plug Jack - 3-1/8" Long	42B	323-0488	4	Socket, Connector - Generator Le
19	304-0469	1	*Rod, Insulator Tubes Mounting		304-0616	t	Resistor Elements & Jack Assy.
20	115-0056	1	*Spring, Insulator, Tube				 Includes Parts Marked *
21	304-0379	8	*Tube, insulator				
22	870-0173	2	*Nut, Push - Insulator Rod Mounting	* -	These parts	s contained	in 304-0616 Resistor Elements and



Jack Assembly.




CONTROL GROUP

REF.	PART NO.	QTY. USED	PART DESCRIPTION
43	305-0425	1	Control, Voltage - Complete
44	3 5-023	ŀ	Transformer
45	323-0450	, I	Housing, Connector Socket
46	303-0144	1	Rheostat
47	303-0032	1 - 1	Knob, Rheostat
48	305-0393	2	Rectifier, Bridge
49	308-0214	i	Switch, Toggle
50	307-0857	1	Relay
5 1	323-0196	I	Base, Receptacle
52	323-0484	7	Socket, Connector
53	301-2771	I	Chassis, Voltage Control
54	301-2544	1	Cover, Regulator



47



REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO,	PART NO.	QTY. USED	PART DESCRIPTION
J	231-0104	l	Adapter, Generator to Engine	26	201-1401		Armature - AC
IC	403-0642	1	Yoke, Lifting - Mounts to Generator	27	210-0383	Į.	Frame, Generator - AC
			Adapter	28	221-0146	2	Shoe, Pole - AC
10	800-0029	4	Screw, H.H 5/16-18 x 1-1/8"- Lifting Yoke Mounting	29	222-1675	ŧ	Coil Assembly, Field - Set of 2 Coils - AC
2	515-0006	ı	Key, Blower to Crankshaft	30	212-0309	1	Rig, Assembly Brush - AC
3	205-0053	1	Blower, Generator	3	305-0448	1	Rectifier - AC
4	232-1256	ı	Plate, Baffle	32	323-0400	1	Housing, Connector Pins (6 Plac
5	*	l	Armature Assembly - includes Blower	33	323-0500	4	Pin, Connector
			and Bearing - DC	34	203-0145	1	Commutator (#BAC45)
6	510-0072	ş	Bearing, Armature (Double Sealed - Pre-Lubricated)	35	800-0050	4	Screw, H.H. Generator Adapter Mounting (3/8-26 x 1")
7	515-0122	1	Key, Drive - Blower to Armature	36	813-0098	5	Screw, R.H.M.S. Scroll, End Bell
8	232-1479	l	Clip, Bearing Stop	İ			(10-32 × 3/8")
9	520-0514	1	Stud, Armature Through	37	850-0030	8	Lockwasher, Band, End Bell &
10	*	1	Coil Assembly Field - Set of 4	l			Scroll (#10)
			Coils, Connected - DC	38	850-0045	2	Lockwasher, Generator through
11	210-0384	1	Frame, Generator - Machined - Less				Stud 5/16
			Coils & Poleshœs - DC	39	862-0015	2 .	Nut, Steel Hex, Generator through
12	221-0145	4	Shoe, Pole - DC]			Stud (5/16-18)
13	212-0229	1	Rig Assembly, Brush - DC	40	850-0055	1	Lockwasher, Armature Stud (7/16
14	212-1105	2	Spring, AC Brush	41	862-0004	J	Nut, Hex Armature Stud (7/16-14)
15	214-0072	2	Brush, AC	42	232-0200		Flatwasher, Armature Stud (7/16)
17	211-0156	1	Bell, End	43	815-0110	3	Screw, Fill Head End Bell and
18	520-0503	2	Stud, Generator Through				Band ($10-32 \times 7/8''$)
19	211-0157	1	Cover, End Bell	44	870-0053	3	Nut, Hex End Bell and Band
20	234-0255	J	Band, End Bell	Ì			(10-32)
21	222-1665	1	Coil Set, Interpole - DC				
22	22 I-0I 4 4	2	interpole - DC	* -	Order by des	scription giv	ring complete Model, Spec, and
23	212-1106	4	Spring, DC Brush		Serial Numbe		, ,
24	214.0047	4	Davids DC	1			



212-1106 214-0067

Brush, DC

CPECIAL PARTS LISTS INDEX FOR FORM NO. 927-1060

MODEL	SPEC.	DATED	FICHE	LOCATION
7.000K-30%	1.T	12/01/78 ***	1 F1	
7.000K-381E	4325T	12/01/78 ***	1. F3	
7.00CK-381E	8874T	12/01/78 ***	1 F3	
7.000K-381E	14917T	12/01/78 ***	1 F5	/



SPECIAL PARTS LIST FOR MODEL	7.0CCK-381E	SPEC _	1T	
FOR STANDARD PARTS REF	ER TO CATALOG	927-1060	KEY NO	1
(PARTS CATALOG ALSO CONTAINS O	COMPONENTS FOR MAJ	OR OPTIONAL FI	EATURES LISTED	BELO\
WIRIN	NG DIAGRAM NO.	60	6-0156-01	

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
201-1312	1	Rotor Assembly, Wound			
222-1675	1	Coil Assembly, Field			

SPECIAL PARTS LIST FOR MODEL	7.0CCK-381E	SPEC
OFECHAL FARIO HOLFUR MICHEL	and the second s	SPEL

FOR STANDARD PARTS REFER TO CATALOG 927-1060 KEY NO.

4325T

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 606-0156-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
201-1312 222-1675	1	Rotor Assembly, Wound Coil Assembly, Field		·	

SPECIAL PARTS LIST FOR MODEL	7.0CCK-381E	SPEC	8874T	
FOR STANDARD PARTS REF		927-1060	KEY NO	_
(PARTS CATALOG ALSO CONTAINS	COMPONENTS FOR MAJO	R OPTIONAL FE	ATURES LISTED BELO	W
Milbi	NC DIACDAM NO	606 0156	. 0.1	

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
	•		, ,	'	
201-1312	1	Rotor Assembly, Wound			
222-1675	1	Coil Assembly, Field			
149-1254	1	Primer, Fuel Pump			
149-1255	1	Bracket, Primer			

000	CLAI	DADTO			MARKE
2 M E	CIAL	PARIS	LIST	FOR.	MODEL

7.0CCK-381E

FOR STANDARD PARTS REFER TO CATALOG 927-1060

KEY NO._

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. _____

606-0156-01

ART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
201-1312 222-1675	1	Rotor Assembly, Wound Coil Assembly, Field			